


Activity 3.1.1 Inputs and Outputs – VEX

Introduction

Robots are similar to humans if you consider that both use inputs and outputs to sense and react to the world.

Most humans use five senses to perceive the world. Based on the input of these senses, your brain makes decisions to activate a response. Through muscle activation, the response can take many forms, including speaking, moving your hand, or running. Robots behave similarly when the world is sensed through physical touch, ambient light intensity, or distance to a solid object. The robot processor translates these inputs and activates a response by triggering a motor or light emitter.

In this activity you will use the ROBOTC software to monitor inputs and control outputs. This will allow you to test the behavior of components before writing a program and to use it as a troubleshooting tool for analyzing program performance.



Equipment


Computer with ROBOTC software POE VEX[®] kit POE VEX[®] Testbed Instructions


Procedure

- 1. Form groups of four and acquire your group's POE VEX Kit under your teacher's direction.
- 2. Within your four student group, form a two-student team known as Team A and a two-student team known as Team B.
- 3. Construct the VEX testbed.
 - a. Team A will construct the VEX Testbed with the exception of the ultrasonic and the light sensor.
 - b. Team B will construct the VEX Testbed with the exception of the servo motor and flashlight.
 - c. At the appropriate time, both teams will exchange testbeds.
- 4. Start the "ROBOTC for VEX Cortex and PIC" software.
- 5. Connect the testbed to the computer using the USB A-A cable.
- 6. Set up the motors and sensors.
 - a. Open the PLTW ROBOTC template:
 - i. Click File > Open Sample Program > PLTW

(This is a folder typically with path C:\Program Files\Robotics Academy\ROBOTC for IFI Cortex and PIC\sample programs\VEX2).

- ii. Open the file PLTWtemplate.
- b. Set platform and communications method:
 - i. Click View > Preferences > Detailed Preferences.
 - ii. In the Platform tab, click the drop down under Platform Type, choose "Innovation First (IFI)", then "Natural Language (VEX Cortex)". Natural Language should appear in the platform type window.
 - iii. Click the drop down under Communication Port, then click "Automatic." Note that this can be changed to USB to ensure that the PC communicates to the Cortex through the USB cable.
 - iv. Click OK.
- c. Click File, Save As, select the folder that your teacher designated, then name the file A3_1_1.
- d. Complete the Project Title, Team Members, Date, and Section. Leave Task Description and Pseudocode blank.
- e. Click Robot.
- f. Click Motors and Sensors Set up.
- g. Add the motors and sensors as shown below.
- h. Save the file in the same location used earlier, A3_1_1.





R

-

-

-

-

-

-

-

-

-

-

Standard Models Motor	s VEX 2.0 Analog Sensors	1-8 VEX 2.0 Digital Sensors 1-1
Port	Name	Туре
dgtl1	limitSwitch	Touch 🗸
dgtl2	bumpSwitch	Touch 👻
dgtl3	quad	Quadrature Encoder 🛛 👻
dgtl4		Quad Encoder 2nd Port 👻
dgtl5	sonar	SONAR (inch) 🗸
dgtl6		SONAR 2nd Port
dgtl7		No Sensor 👻
dgtl8		No Sensor 🗸
dgtl9		No Sensor 🗸
dgtl10		No Sensor 🗸
dgtl11		No Sensor 👻
dgtl12	green	VEX LED -

Motors and Sensors Setup

7. Obtain the teacher's approval before proceeding to the next step.

Instructor's Signature Date

- 8. Power on the Cortex.
- 9. View motor and sensor debugger windows.
 - a. Click Robot.
 - b. Click Compile and Download Program. Leave the Debug window open.
 - c. Click Robot, Debug Windows, then Motors.
 - d. If there is not a Sensor and Motors tab available at the bottom of the window, add them through the next steps. Click Robot, Debug Windows, then Sensors.
 - e. Increase the debugger window area at the bottom to view the motor and sensor values as shown below. Note that this window can be viewed any time by clicking Robot then Debugger.

- 🖬 🖉 💷 🖻 😭	n a 🏹 🕅	8 A, A @@,	4338				
	× A3_1_11n	outsOutputs_ROBOTC_VEX	NO LINK.c* PLTWten	nplate.c			
	1	∦pragma config		lineFollower,	sensorLineFollower)		
Constructs	2	<pre>#pragma config</pre>			sensorPotentiometer)	Program Debug	3
tural Language	3	<pre>#pragma config</pre>		lightSensor,	sensorReflection)		2400
	4	<pre>#pragma config #pragma config</pre>			sensorTouch) sensorTouch)	Debug Status Refresh	Rate
	6	<pre>#pragma config #pragma config</pre>			sensorOuadEncoder)	Start Suspend Once	
	7	#pragma config			sensorSONAR inch)	Start	c
	8	pragma config			sensorDigitalOut)	Step Into Step Over Step Out Pause Re	afresh
	9	#pragma config					
	10	#pragma config		rightMotor,		Clear Al	
	11	<pre>#pragma config</pre>					
	12	<pre>#pragma config</pre>					
	13	//*!!Code autor	natically gener	ated by 'ROBOTC' confi	guration wizard !!*//		
	Motors						
	Index	Motor	Power				
	port1	port1	0				
	port2	port2	0				
	port3 port4	port3	0				
	pon4 port5	port4 port5	0				
	port6	port6	0				
	port7	port7	0				
	port8	port8	0				
	port9	port9	0				
	port10	port10	0				

Motor and Sensor Windows

10. Verify motor outputs.

- a. Click the Motors tab at the bottom on the window.
- b. Change the right motor value.
 - i. Click Port 2 under the Power column.
 - ii. Enter several values ranging from -127 to 127, then press Enter on the keyboard or click away from the value entry window.
 - iii. Record your observations in your engineering notebook, including the threshold power setting for the motor to turn.



- c. Change the left motor value.
 - i. Click Port 3 under the Power column.
 - ii. Enter several values ranging from -127 to 127, then press Enter on the keyboard or click away from the value entry window after each value is entered.
 - iii. Record your observations in your engineering notebook, including the threshold power setting for the motor to turn.
- 11. Verify analog sensor inputs.
 - a. Click the Sensors tab.
 - b. In the Program Debug pop-up, ensure that inputs and outputs are being refreshed continuously. If not, choose "Continuous" from the Refresh drop-down menu.

Program Debug	? 🛛
Debug Status Start Suspend Step Into	Refresh Continuous 🔻
Clear All	

Continuous Option


- c. Observe the line follower sensor.
 - i. View the value shown beside the lineFollower (in1) label.
 - ii. Change the line follower immediate environment and observe the effect on the lineFollower value. Use a dark and light color within 1/4 1/8 in. to see the change in the sensor value.
 - iii. Record your observations in your engineering notebook.



- d. Observe the potentiometer.
 - i. View the value shown beside the potentiometer (in2) label.
 - ii. Change the potentiometer setting and observe the effect on the potentiometer value. Rotate the potentiometer to change the sensor input. Do not force the potentiometer beyond the CW and CCW physical stops.
 - iii. Record your observations in your engineering notebook.
 - iv. Calculate the angle change between whole number values in your engineering notebook. Use the protractor below to measure an angle.



Potentiometer



Protractor

- 12. Verify digital sensor inputs.
 - a. Verify that the Sensors tab is selected in the debugger window.
 - b. Observe the limit switch sensor.
 - i. View the value shown beside the limitSwitch (dgtl1) label.
 - ii. Change the limit switch environment and observe the effect on the limitSwitch value. Your finger can be used to activate the limit switch.
 - iii. Record your observations in your engineering notebook.



Limit Switch

- c. Observe the bumper switch sensor.
 - i. View the value shown beside the bumpSwitch (dgtl2) label.
 - ii. Change the bumper switch environment and observe the effect on the bumpSwitch value. Your finger can be used to activate the bumper switch.
 - iii. Record your observations in your engineering notebook.



Bumper Switch

- d. Observe the optical encoder sensor.
 - i. View the value shown beside the quad (dgtl3) label.
 - ii. Change the optical encoder environment and observe the effect on the quad value. Rotate the optical encoder. Note that there is no CW or CCW physical stop therefore it can be turned indefinitely in a direction.
 - iii. Record your observations in your engineering notebook.



Optical Encoder

- e. Change the green LED light value.
 - i. Click the field beside green (dgtl12) under the Value column.
 - ii. Enter a 0 value, then press Enter on the keyboard or elsewhere in the dialog window. Did the LED respond as you expected?
 - iii. Enter a 1 value, then press Enter on the keyboard or click away from the value entry window. Did the LED respond as you expected?
 - iv. Record your observations in your engineering notebook.



Green LED

13. Obtain the teacher's approval before proceeding to the next step.

Instructor's Signature _____ Date _____

14. Verify available output and inputs based on the testbed created.

Team A:

- a. Change the servo motor value.
 - i. Click Port 9 under the Power column.
 - ii. Enter several values ranging from -127 to 127, then press Enter on the keyboard or click away from the value entry window.

- iii. Record your observations in your engineering notebook, including the servomotor physical range.
- iv. Calculate the angle change between whole number values in your engineering notebook. Use the protractor above to measure an angle.



Servo Motor

- b. Change the flashlight value.
 - i. Slide the physical switch on the flashlight to the on position.
 - ii. Click Port 1 under the Power column.
 - iii. Enter several values ranging from -127 to 127, then press Enter on the keyboard or click away from the value entry window. This allows the value to be updated. Note that the flashlight needs a negative value in the debugger window.
 - iv. Turn flashlight off.
 - v. Record your observations in your engineering notebook.



Flashlight

Team B:

- a. Observe the ultrasonic sensor.
 - i. View the value shown beside the sonar (dgtl5) label.
 - ii. Change the ultrasonic environment with a solid object in front of the ultrasonic sensor. Observe the effect on the sonar value.
 - iii. Record your observations in your engineering notebook.



Ultrasonic

- b. Observe the light sensor.
 - i. View the value shown beside the lightSensor (in3) label.
 - ii. Change the light sensor's immediate environment by activating the flashlight and shine it on the light sensor. Use your hand to shield the light to the sensor to change the sensor input. Observe the effect on the lightSensor value.
 - iii. Record your observations in your engineering notebook.



Light Sensor

- 15. Exchange testbeds with the counterpart team within your group to explore the components present on the partner testbed.
- 16. Repeat the step above with your testbed.
- 17. Obtain the teacher's approval upon completing this final step.

Instructor's Signature	Date
------------------------	------

Conclusion

- 1. Describe how these motors and sensors may be used.
- 2. Describe scenarios where the motors or sensors did not respond as you would predict.